





FN+MULTIMEDIA FUNCTION KEYS




MT-K4130
WIRELESS KEYBOARD


STEPS FOR USAGE



1. Please insert the batteries into the battery compartments of the keyboard.



2. Please take the USB receiver out of the accessory bag.



3. Please Insert the USB receiver into the USB port of your computer.

GENERAL

All MEETION brand products comply with US FCC standards (FCC ID: 2A706-MT062726), EU CE standards, CAUK standards, and Bluetooth BQB certification.

The product is manufactured in accordance with RoHS standards.

PRECAUTIONS

1. This product contains a rechargeable lithium battery.

(1) Do not dismantle, strike, crush, or expose it to fire.

(2) Stop using it immediately if severe swelling occurs.

(3) Do not place it in a high-temperature environment.

2. Do not use this device near water.

3. Only use a dry cloth to clean this product.

4. Please follow the manufacturer's instructions for use.

5. If the device is damaged, for example, if liquid enters it, if it gets wet in the rain or becomes damp, or if it cannot operate normally, it must be repaired. For repair matters, it should be entrusted to qualified maintenance personnel.

KIND TIPS

If the product is not in use for an extended period, it is recommended to charge it every three months to activate the lithium battery and prevent battery failure due to prolonged non-use.

Meetion

TECHNICAL SUPPORT

Having technical problems with this product?

Send an email to service@meetion.com

For more information please visit:

www.meetion.com