





USER'S MANUAL BTK9552



fn + Q = iOS **fn + W = Android** **fn + E = Windows** **fn + R = Mac**

Keyboard touchpad

! Before using the keyboard, please confirm that it matches the operating system of the device (computer, phone, etc.) you intend to use it with.

Keyboard Indicator Lights

Icon	Indicator	Color	Definition
*1	Bluetooth 1 Channel	Blue	Blue light flashing rapidly: Bluetooth 1 is entering pairing mode. (Long press:Bluetooth button) Blue light flashing rapidly: Bluetooth 1 is entering reconnecting mode. The blue light stays on for 5 seconds and then goes off: Successfully reconnected in Bluetooth 1 mode.
*2	Bluetooth 2 Channel	Blue	Blue light flashing rapidly: Bluetooth 2 is entering pairing mode. (Long press:Bluetooth button) Blue light flashing rapidly: Bluetooth 2 is entering reconnecting mode. The blue light stays on for 5 seconds and then goes off: Successfully reconnected in Bluetooth 2 mode.
*3	Bluetooth 3 Channel	Blue	Blue light flashing rapidly: Bluetooth 3 is entering pairing mode. (Long press:Bluetooth button) Blue light flashing rapidly: Bluetooth 3 is entering reconnecting mode. The blue light stays on for 5 seconds and then goes off: Successfully reconnected in Bluetooth 3 mode.
A	Caps lock	Green	Green light is always on: Caps lock is on.
⚡	Low battery	Red	Red light flashing rapidly: The device is low on power.
	Charging	Green	Green light is on: The device is currently charging. Green light indicator is off: The device is fully charged.

Keys and Function

- fn** + **[Touchpad Icon]** = Disable the touchpad feature
- fn** + **[Esc]** = Fn Lock function
- fn** + **[Enter]** = Long press restore Bluetooth to factory settings
- fn** + **[Q]** = iOS system
- fn** + **[W]** = Android system
- fn** + **[E]** = Windows system
- fn** + **[R]** = Mac system
- fn** + **[Home]** = Home
- fn** + **[End]** = End
- fn** + **[PgUp]** = PgUp
- fn** + **[PgDn]** = PgDn



When Fn lock is closed,you need to press Fn+Shortcut to achieve the shortcut function.(Press Fn+esc to open/close Fn lock)
The emoji key function supports Windows, MacBook (macOS), iPad (iPadOS), and Android Samsung devices, but does not support iPhone (iOS).

Keys and Function

Function Keys	*1 F1	*2 F2	*3 F3	*4 F4	*5 F5	*6 F6	*7 F7	*8 F8	*9 F9	*10 F10	*11 F11	*12 F12
iOS	Bluetooth 1	Bluetooth 2	Bluetooth 3	Brightness-	Brightness+	Application switching	Search	Screenshot	Mute	Volume-	Volume+	Emoji
Android	Bluetooth 1	Bluetooth 2	Bluetooth 3	Brightness-	Brightness+	Application switching	Search	Screenshot	Mute	Volume-	Volume+	Emoji
Windows	Bluetooth 1	Bluetooth 2	Bluetooth 3	Brightness-	Brightness+	Application switching	Search	Screenshot	Mute	Volume-	Volume+	Emoji
Mac	Bluetooth 1	Bluetooth 2	Bluetooth 3	Brightness-	Brightness+	Application switching	Search	Screenshot	Mute	Volume-	Volume+	Emoji

Bluetooth instructions

- Switch to the "ON" position on the up to turn on the device.
- Press the*1/*2/*3 key to switch to Bluetooth mode; the corresponding Bluetooth 1 / Bluetooth 2 / Bluetooth 3 indicator light will turn blue and begin to blink.
- Find the device named "MeetionKB1" / "MeetionKB2" / "MeetionKB3" in your computer's Bluetooth settings and connect it!






Keyboard System and Function Switching Guide

- Press FN+Q to switch to the iOS system, press FN+W to switch to the Android system.
- Press FN+E to switch to the Windows system, press FN+R to switch to the Mac system.
- Press Fn and the Spacebar to turn the touchpad on or off.

User Manual for Touchpad Functions on Windows System

- ### One Finger
- Click:** Press with a single finger until you feel a click. Function: Left mouse button.
 - Swipe:** Single-Finger Move. Function: Cursor Sliding.
 - Tap:** Two-Finger Tap. Function: Two-Finger Right Click.
- ### Double Fingers
- Swipe:** Two-Finger Swipe Up, Down, Left, and Right. Function:Mouse Wheel.
 - Spread Gesture:** The fingers are placed close together, opened to enlarge. Function: Zoom In.
 - Pinch Gesture:** The fingers are placed close together, pinched to shrink. Function: Zoom Out.

Three Fingers



Tap: Three-Finger Tap.
Function: Search function.


Swipe: Swipe up with three points, pause and then lift your finger.
Function: Arrange Current Applications.
Shortcut Key: WIN+TAB.

Swipe: Swipe down with three points, pause and then lift your finger.
Function: Show Desktop.
Shortcut Key: WIN+D.

Swipe: Three-Finger Left Swipe.
Function: Switch Active Window to the Left.
Shortcut Key: Alt+ Shift+Tab.

Swipe: Three-Finger Right Swipe.
Function: Switch Active Window to the Right.
Shortcut Key: Alt+Tab.




Four Finger



Tap: Four-Finger Tap.
Function: Open Action Center.
Shortcut Key: WIN+A.

User Manual for Touchpad Functions on iOS System(Custom settings)

One Finger








Click: Press with a single finger until you feel a click.
Function: Single Point (Custom).

Swipe: Single-Finger Move.
Function: Cursor Sliding.

Lightly tap twice with one finger, then hold and slide: Point and hold the item, then change it with your finger on the trackpad to move.
Function: Drag and drop.

Double Fingers



Tap: Two-Finger Tap.
Function: Two-Finger Right Click.


Swipe: Two-Finger Swipe Up, Down, Left, and Right.
Function: Mouse Wheel.

Swipe: Two-finger swipe left and right.
Function: Mouse left and right on the screen.

Spread Gesture: The fingers are placed close together, opened to enlarge.
Function: Zoom In (Web page).

Pinch Gesture: The fingers are placed close together, pinched to shrink.
Function: Zoom Out (Web page).



Four Finger







Tap: Four-Finger Tap.
Function: Regional screenshot.
Shortcut Key: Cmd+Shift+3.

1.Equipment must support touch

2.Custom settings (when wireless pairing is successful): Settings→Accessibility→Touch→Assistive Touch→Devices→Connected devices→Customize Additional Buttons→Set the action on the trackpad→Select instruction

 +  Turn on/off touchpad function

Three Fingers



Tap: Three-Finger Tap.
Function: Home screen (Custom).


Swipe: Swipe up with three points, pause and then lift your finger.
Function: Show/Hide the bottom app bar.
Shortcut Key: Cmd+Alt+D.

Swipe: Swipe down with three points, pause and then lift your finger.
Function: Open all active windows (double tap the home button).
Shortcut Key: Cmd+Shift+Tab.

Swipe: Three-Finger Left Swipe.
Function: Switch Active Window to the Left.
Shortcut Key: Cmd+Shift+Tab.

Swipe: Three-Finger Right Swipe.
Function: Switch Active Window to the Right.
Shortcut Key: Cmd+Tab.




Four Finger



Tap: Four-Finger Tap.
Function: Regional screenshot.
Shortcut Key: Cmd+Shift+3.

User Manual for Touchpad Functions on Mac System

One Finger






Click: Press with a single finger until you feel a click.
Function: Left mouse button.

Swipe: Single-Finger Move.
Function: Cursor Sliding.

Lightly tap twice with one finger, then hold and slide: Point and hold the item, then change it with your finger on the trackpad to move. it.
Function: Drag and drop.

Double Fingers




Tap: Two-Finger Tap.
Function: Two-Finger Right Click.

Swipe: Two-Finger Swipe Up, Down, Left, and Right.
Function: Mouse Wheel.

Spread Gesture: The fingers are placed close together, opened to enlarge.
Function: Zoom In (Web page).

Pinch Gesture: The fingers are placed close together, pinched to shrink.
Function: Zoom Out (Web page).




Four Fingers



Tap: Four-Finger Tap.
Function: Region screenshot.
Shortcut Key: Cmd+Shift+4.

User Manual for Touchpad Functions on Android System




One Finger



Click: Press with a single finger until you feel a click.
Function: Left mouse button.

Swipe: Single-Finger Move.
Function: Cursor Sliding.

Double Fingers



Swipe: Two-Finger Swipe Up, Down, Left, and Right.
Function: Mouse Wheel.

GENERAL

All MEETION brand products comply with US FCC standards (FCC ID: 2A7O6), EU CE standards/CAUK standards, Bluetooth BQB certification.The product is made in accordance with RoHS standard.

PRECAUTIONS

1.This product contains a rechargeable lithium battery. (1)Do not dismantle,strike,crush,or put it into a fire. (2)Stop using it immediately if severe swelling occurs. (3)Do not place it in a high-temperature environment.

2.Do not use this device near water.

3.Only use a dry cloth to clean this product.

4.Please follow the manufacturer's instructions for use.

5.If the device is damaged,for example,if liquid enters it,if it gets wet in the rain or becomes damp,or if it cannot operate normally,it must be repaired.For repair matters,it should be entrusted to qualified maintenance personnel.

KIND TIPS

If the product is not in use for a long time,it is recommend- ed to charge it every three months to activate the lithium battery inside the product and prevent battery failure due to long periods of non-use.

Meetion

TECHNICAL SUPPORT

Having technical problems with this product? Send an email to service@meetion.com For more information please visit: www.meetion.com

Troubleshooting:

What can I do if MEETION keyboard Fail to connect?

Only supports Bluetooth connection (no 2.4G connection).

1. On your device, forget/delete the keyboard's previous Bluetooth pairing.

2. Press and hold the Bluetooth button for 5s to reset.

3. On your device, search for the keyboard, and reconnect.

Touchpad lagging or freezing—can it be fixed?

1. Tap any key to wake first, then check if the low-battery light flashes (charge if low). Stay within 10 ft; re-pair if needed.

2. Windows: raise Pointer Speed & disable "Enhance pointer precision."

3. macOS: Trackpad > Tracking Speed → fast.

Touchpad not Working? It's Not Responding?

Press fn + Spacebar to check if trackpad is off.

Check the device battery charge, re-pair via Bluetooth (remove and re-add).

For iOS 13.4+: Enable via Settings > Accessibility > Touch > AssistiveTouch. Reboot trackpad and device.