




USER'S MANUAL

US UK
CA

Keyboard touchpad

Keyboard Indicator Lights

Icon	Indicator	Color	Definition
⌂	Bluetooth 1 Channel	Blue	Blue light flashing rapidly: Bluetooth 1 is entering pairing mode. The blue light stays on for 5 seconds and then goes off: Successfully reconnected in Bluetooth 1 mode.
⌂	Bluetooth 2 Channel	Blue	Blue light flashing rapidly: Bluetooth 2 is entering pairing mode. The blue light stays on for 5 seconds and then goes off: Successfully reconnected in Bluetooth 2 mode.
⌂	Bluetooth 3 Channel	Blue	Blue light flashing rapidly: Bluetooth 3 is entering pairing mode. The blue light stays on for 5 seconds and then goes off: Successfully reconnected in Bluetooth 3 mode.
A	Caps lock	Green	Green light is always on: Caps lock is on.
⚡	Low battery	Red	Red light flashing rapidly: The device is low on power.
⚡	Charging	Green	Green light is on: The device is currently charging. Green light indicator is off: The device is fully charged.

Keys and Function

- 1. Fn + [Esc] = Turn off the touchpad
- 2. Fn + [Enter] = Long press restore Bluetooth to factory settings
- 3. Fn + [Q] = iOS system
- 4. Fn + [W] = Android system
- 5. Fn + [E] = Windows system
- 6. Fn + [R] = Mac system
- 7. Fn + [Home] = Home
- 8. Fn + [End] = End
- 9. Fn + [PgUp] = Pgup
- 10. Fn + [PgDn] = Pgdn

Default Multimedia Keys, to use the F1-F12 function keys, you need to hold down the Fn key while pressing the corresponding F1-F12 key.

The emoji key function supports Windows, MacBook (macOS), iPad (iPadOS), and Android Samsung devices, but does not support iPhone (iOS).

Keys and Function

Function Keys	⌂	⌂	⌂	F4	F5	F6	F7	F8	F9	F10	F11	F12
iOS	Bluetooth 1	Bluetooth 2	Bluetooth 3	Application switching	Search	Previous	Play/Pause	Next	Mute	Volume-	Volume+	Emoji
Android	Bluetooth 1	Bluetooth 2	Bluetooth 3	Application switching	Search	Previous	Play/Pause	Next	Mute	Volume-	Volume+	Emoji
Windows	Bluetooth 1	Bluetooth 2	Bluetooth 3	Application switching	Search	Previous	Play/Pause	Next	Mute	Volume-	Volume+	Emoji
Mac	Bluetooth 1	Bluetooth 2	Bluetooth 3	Application switching	Search	Previous	Play/Pause	Next	Mute	Volume-	Volume+	Emoji

Bluetooth instructions

- Switch to the "ON" position on the up to turn on the device.
- Press the ⌂/⌂/⌂ key to switch to Bluetooth mode; the corresponding Bluetooth 1 / Bluetooth 2 / Bluetooth 3 indicator light will turn blue and begin to blink.
- Find the device named "Meetion-KB-BT1" / "Meetion-KB-BT2" / "Meetion-KB-BT3" in your computer's Bluetooth settings and connect it!

Keyboard System and Function Switching Guide

- Press FN+Q to switch to the iOS system, press FN+W to switch to the Android system.
- Press FN+E to switch to the Windows system, press FN+R to switch to the Mac system.
- Press Fn and the Spacebar to turn the touchpad on or off.

Due to the differences in system versions, the gesture controls may vary. Before using the keyboard, please confirm that it matches the operating system of the device (computer, phone, etc.) you intend to use it with.

User Manual for Touchpad Functions on Windows System

- One Finger**
 - Click:** Press with a single finger until you feel a click.
 - Function:** Left mouse button.
- Double Fingers**
 - Tap:** Two-Finger Tap.
 - Function:** Two-Finger Right Click.
- Three Fingers**
 - Tap:** Three-Finger Tap.
 - Function:** Search function.
- Four Finger**
 - Tap:** Four-Finger Tap.
 - Function:** Open Action Center.
 - Shortcut Key:** WIN+A.

