





USER'S MANUAL

BTK1200

Bluetooth Connection Instructions:



Color Adjustment:

7 colors in total

Fn + = red, green, blue, white, purple, blue, yellow

Fn + = yellow, blue, purple, white, blue, green, red

Brightness adjustment:

= Brightness adjustment sequential charging: 1st, 2nd, 3rd, off, a total of four cycles

Indicator light description

A Caps Lock Indicator	Press "Caps Lock" key, the indicator is on blue light	Bluetooth Indicator	Press combo keys "Fn"+ "C" to pair, the indicator flashes blue light it will be constant on after it pairs successfully	Power Indicator	The indicator blinks red light means keyboard is in low battery	Charging Indicator	The indicator light is constant on when keyboard is charging, it will be off when charging is finished.
-----------------------	---	---------------------	---	-----------------	---	--------------------	---

Lock/unlock with Fn key (Unlocked state is default)

Lock: Long Press , then press , Bluetooth and Caps Lock indicators flash once together, Fn key is locked now, if you want to type F1-F12 and Ins keys just press them. No change on other combo keys with Fn.

Unlock: Long press , then press , Bluetooth indicator flashes once, Fn keys is unlocked now, if you want to type F1-F12 and Ins keys, you should press them with Fn together.

Touchpad function description:

One Finger Click
-Left Mouse Button

One Finger Swipe
-Move Cursor

Three Fingers Click
-Search

Three Fingers Left Shift
- Switch tasks to the left

Left Mouse Button
-Select the Target and Drag

Two Fingers Zoom
-Zoom in (out)

Three-fingers slides up
-Multi task window

Three Fingers Right Shift
- Switch tasks to the right

Two Fingers Click
- Right Mouse Button

Two Fingers Swipe
Vertically Horizontally
-Scroll Vertically Horizontally

Three point swipe down
- return to desktop

Four Fingers Click
- Open Control Center