




USER'S MANUAL
DirectorD-KB




 In Mac system, the default shortcut keys are function keys.
 In Windows system, the default shortcut keys are F1-F12.
when Fn lock is closed, you need to press Fn+Shortcut to achieve the shortcut function.(Press Fn+Esc to open/close Fn lock)


	Red light flashing: The keyboard's battery is low.		Previous		Play&Stop		Next		Volume+		Volume-		Mute
	Green light is always on: The NUM keypad is active.		Calculator		Win.Copilot/ Mac.Switching Applications		Brightness-		Brightness+		Search		Application switching
	Green light is always on: The Caps Lock is activated.		Win: dictate Mac: Siri		Dormant		Copy		Paste		Cut		Email
	Green light is always on: The FN Lock is activated.		Music		Voice switching		Emoji		Lock screen				

 Fn + W: Switch the keyboard to macOS ; Fn + Q: Switch the keyboard to Windows.
 When the battery is low, the product may experience delays. Please replace the battery in a timely manner.


Usage instruction




1 Install the batteries into the keyboard battery compartments.




2 Turn the keyboard power switch to the ON position.




3 Please open the battery cover on the back of the keyboard and take out the receiver from the storage battery compartment.



4 Please take the USB-C Adapter out of the accessory bag.



5 Insert the USB receiver into the USB port of the computer.



6 Press FN+Q to switch to the Windows system, press FN+W to switch to the Mac system;

Troubleshooting:

How to deal with key failure, intermittent repeated input or no response?

1. Clean up the dust and debris under the keycaps, and use a compressed air can to blow away the debris in the gap.
2. Replace the USB interface of the computer and reconnect it to eliminate the problem of poor interface contact.
3. Reboot the devices, turn off the keyboard and restart it.
4. Keep the straight line distance between the receiver and the keyboard within 33 centimeters.

What should I do if I have replaced the battery with a new one and it still indicates that the battery is not sufficiently charged or does not work?

1. Check whether the positive and negative battery terminals are correctly installed, and clean the metal contacts of the battery compartment to ensure good contact.
2. Turn off 2.4GHz signal sources such as Bluetooth and routers around the keyboard to minimize the abnormal power consumption caused by interference.

How do I troubleshoot a keyboard that is not compatible with my work computer?

1. Re-insert the USB receiver and plug it in tightly.
2. Press Win+Q (Windows systems) or Win+W (Mac systems) to switch systems.
3. The keyboard is compatible with Windows 10/11, macOS 10.12 and higher. Not compatible with: Windows 8.1, macOS 10.13 or below, Lite Linux and Customized Linux.

What can I do to improve the noisy keyboard?

1. Adjust your typing habits by pressing keys gently and avoiding hard tapping.
2. Put shock-absorbing pads or silicone pads on the bottom of the keyboard to absorb the vibration transmission when you press the keys.
3. Check whether the keycaps are firmly installed, loose keycaps will increase the crash noise, re-press the keycaps to make sure they are tightly seated.



1. Batteries are not included, so you will need to prepare them yourself.
2. Please open the battery cover on the back of the keyboard and take out the receiver from the storage battery compartment.

GENERAL

All MEETION brand products comply with US FCC standards (FCC ID: 2A706-MT062726), EU CE standards, and CAUK standards. The product is manufactured in accordance with RoHS standards.

PRECAUTIONS

1. Do not dismantle, strike, crush, or expose it to fire.
2. Stop using it immediately if severe swelling occurs.
3. Do not place it in a high-temperature environment.
4. Do not use this device near water.
5. Only use a dry cloth to clean this product.
6. Please follow the manufacturer's instructions for use.
7. If the device is damaged (e.g., if liquid enters it, if it gets wet in the rain, or if it becomes damp), or if it does not operate normally, it must be repaired. Repairs should be entrusted to qualified maintenance personnel.

Meetion

TECHNICAL SUPPORT

Having technical problems with this product?
Send an email to service@meetion.com
For more information please visit:
www.meetion.com