





USER’S MANUAL
K2000




 0	Green light always on: NUM keypad on Green light off: NUM keypad off		Brightness-		Brightness+		Multitasking		Search
 o	Green light always on: Caps lock on Green light off: Caps lock off		Screenshot		Switch input method		Previous		Play&Stop
 o	Green light always on: Scroll Lock on Green light off: Scroll Lock off		Next		Mute		Volume-		Volume+
 o	Green light always on: FN Lock on Green light off: FN Lock off		Emoji		Lock screen		Scroll Lock		Input method
	FN + Right Shift: Light Brightness Adjustment: 25% --> 50% --> 75% --> 100% -->Off								
	FN + Right Enter: Changing the Backlight Mode: 1.RGB Breathing 2.Red 3.Green 4.Blue 5.White 6.Purple 7.Cyan 8.Yellow 9.RGB Breathing								

  The emoji key function supports Windows, MacBook (macOS), iPad (iPadOS), and Android Samsung devices, but does not support iPhone (iOS).

Note: K2000 keyboard enters auto sleep mode with backlight off after 5 minutes of no operation. Press any key to wake the backlight.

Usage Guidelines



Simply plug the keyboard cables into the USB ports to start using the keyboard.

 The USB-A interface and the USB-A to Type-C adapter are separable. When you need to use the USB-A interface separately, you can detach the adapter.

PRECAUTIONS

1. Stop using the device immediately if severe swelling occurs.
2. Do not place it in a high-temperature environment.
3. Do not use this device near water.
4. Only use a dry cloth to clean this product.
5. Please follow the manufacturer's instructions for use.
6. If the device is damaged—for example, if liquid enters it, it gets wet in the rain, or it becomes damp, or if it cannot operate normally—it must be repaired. Repairs should be entrusted to qualified maintenance personnel.

Troubleshooting:

How to deal with key failure, intermittent repeated input or no response?

1. Clean up the dust and debris under the keycaps, and use a compressed air can to blow away the debris in the gap.
2. Replace the USB interface of the computer and reconnect it to eliminate the problem of poor interface contact.
3. Reboot the devices, turn off the keyboard and restart it.
4. Keep the straight line distance between the receiver and the keyboard within 33 centimeters.

How do I troubleshoot a keyboard that is not compatible with my work computer?

1. Unplug the keyboard's USB cable and plug it back in firmly, making sure the connector is fully seated in your computer's USB port (you can also try a different USB port) to rule out issues with a loose connection.
 2. Press Win+Q (Windows systems) or Win+W (Mac systems) to switch systems.
 3. The keyboard is compatible with Windows 10/11, macOS 10.12 and higher.
- Not compatible with: Windows 8.1, macOS 10.13 or below, Lite Linux and Customized Linux.

What can I do to improve the noisy keyboard?

1. Adjust your typing habits by pressing keys gently and avoiding hard tapping.
2. Put shock-absorbing pads or silicone pads on the bottom of the keyboard to absorb the vibration transmission when you press the keys.
3. Check whether the keycaps are firmly installed, loose keycaps will increase the crash noise, re-press the keycaps to make sure they are tightly seated.

Meetion

TECHNICAL SUPPORT

Having technical problems with this product?
Send an email to service@meetion.com
For more information please visit:
www.meetion.com